

Maintenance schedule

I: INSPECT C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE T: TOP UP O: OIL CHANGE E: EMISSION CHECK

The following Maintenance Schedule specifies all maintenance required to keep your vehicle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Hero MotoCorp by properly trained and equipped technicians. Your Authorised Distributor/Dealer meets all of these requirements.

Ensure that each paid service is availed within **90** days or **3000** km from the date of previous service, whichever is earlier.

- ↘ To be serviced by your Authorised Distributor/Dealer unless the owner has the relevant tools, technical information and is technically qualified.
- ✗ In the interest of safety, we recommend that these jobs are carried out only by your Authorised Distributor/Dealer.

Note-1 : At higher odometer readings, repeat the frequency interval established here.

Note-2 : Replace air cleaner element once in every **15000** km or early replacement may be required when riding in dusty areas.

Note-3 : Replace engine oil once in every **6000** km. Top up if the oil level is at or near the lower level mark

Note-4 : Visit Authorised Distributor/Dealer for inspection, cleaning, lubrication and adjustment of drive chain at every **2000** km.

Note-5 : Replace once in every two years or **30000** km, whichever is earlier.

Note-6 : Inspect & maintain specified torque.

Note-7 : Inspect the wheel bearings free play, replace if necessary.

Note-8 : Inspect for any play in the mounting bushes, replace if necessary.

Note-9 : Check idle CO emission along with idle rpm/idle CO adjustment (if required).

Note-10 : Inspect the canister hoses for deterioration, damage or loose connections and canister for cracks or other damages.












Note: Always wipe the water from the vehicle after washing. Use clean soft cloth or pressurized air for completely drying the water.

MAINTENANCE SCHEDULE

Dear Customer,

We would strongly recommend the following schedule, to keep your vehicle in perfect running condition and healthy environment. Vehicle subjected to severe use or ridden in dusty area will require more frequent servicing.

ITEMS	SERVICE	1 st	2 nd	3 rd	4 th	5 th	6 th	7 th	8 th	9 th	10 th	11 th	
	DAYS	1st 60	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	
	Km Note-1	500-750	3000-3500	6000-6500	9000-9500	12000-12500	15000-15500	18000-18500	21000-21500	24000-24500	27000-27500	30000-30500	
Fuel Line		I	I	I	I	I	I	I	I	I	I	I	
Throttle Operation		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	
Bystarter Operation		I	I	I	I	I	I	I	I	I	I	I	
Carburetor/Engine Idle Speed		C, A	A	C, A	A	C, A	A	C, A	A	C, A	A	C, A	
Air Cleaner Element	Note-2	Do not open air cleaner element unless there is a drivability problem						R					R
Spark Plug		I, C, A	I, C, A	I, C, A	I, C, A	R	I, C, A	I, C, A	I, C, A	I, C, A	R	I, C, A	
Valve Clearance		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	
Engine Oil	Note-3	O	I, T	O	I, T	O	I, T	O	I, T	O	I, T	O	
Engine Oil Strainer Screen		C		C		C		C		C		C	
Engine Oil Centrifugal Filter		C		C		C		C		C		C	
Electric Starter		I	I	I	I	I	I	I	I	I	I	I	
Oil Circulation		I	I	I	I	I	I	I	I	I	I	I	
Drive Chain	Note-4	I,C,L,A at every 2000 km					I,C,L,A at every 2000 km						
Drive Chain Slider			I	I	I	I	I	I	I	I	I	I	
Battery Voltage		I	I	I	I	I	I	I	I	I	I	I	
Brake Shoe		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	

ITEMS		SERVICE	1 st	2 nd	3 rd	4 th	5 th	6 th	7 th	8 th	9 th	10 th	11 th	
		DAYS	1st 60	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90
		Km Note-1	500-750	3000-3500	6000-6500	9000-9500	12000-12500	15000-15500	18000-18500	21000-21500	24000-24500	27000-27500	30000-30500	
	Disc wear/Pad wear		I	I	I	I	I	I	I	I	I	I	I	
	Brake Fluid	Note-5	I	I	I	I	I	I	I	I	I	I	I	
	Brake System (Brake Cam & Brake Pedal)			C, L		C, L		C, L		C, L		C, L		
	Stop Lamp Switch		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	
	Headlamp Focus		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	
	Clutch		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	
	Side Stand/Main Stand		L	L	L	L	L	L	L	L	L	L	L	
	i3s System		I	I	I	I	I	I	I	I	I	I	I	
	Nut, Bolts & Fasteners	Note-6	I	I	I	I	I	I	I	I	I	I	I	
	Wheels Bearings	Note-7	I	I	I	I	I	I	I	I	I	I	I	
	Wheels/Tyres		I	I	I	I	I	I	I	I	I	I	I	
	Steering Head Bearing		I	I, A	I	I, A	I, L, A	I	I, A	I	I, L, A	I	I, A	
	Front Suspension/Oil	Note-5	I	I	I	I	I	I	I	I	I	I	R	
	Rear Suspension	Note-8	I	I	I	I	I	I	I	I	I	I	I	
	Secondary Air Injection				I		I		I		I		I	
	Muffler (Catalytic Converter)	Note-9			I, E		I, E		I, E		I, E		I, E	
	Evaporative Emission Control System	Note-10	I	I	I	I	I	I	I	I	I	I	I	