

MAINTENANCE SCHEDULE

I: INSPECT C: CLEAN R: REPLACE A: ADJUST O: OIL CHANGE
L: LUBRICATE T: TOP UP E: EMISSION CHECK

The following maintenance schedule specifies all maintenance required to keep your vehicle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of HMCL Niloy Bangladesh Ltd. by properly trained and equipped technicians. Your Authorised Distributor/Dealer meets all of these requirements.

Ensure that each paid service is availed within **90** days or **3000** km from the date of previous service, whichever is earlier.

- ↘ To be serviced by your Authorised Distributor/Dealer unless the owner has the relevant tools, technical information and is technically qualified.
- ✕ In the interest of safety, we recommend that these jobs are carried out only by your Authorised Distributor/Dealer.

Note-1: At higher odometer readings, repeat the frequency interval established here.

Note-2: More frequent cleaning may be required when riding in dusty areas.

Note-3: Replace engine oil once in every **6000** km. Top up once in every **3000** km.

Note-4: Visit Authorised Distributor/Dealer for inspection, cleaning, lubrication and adjustment of drive chain at every **2000** km.

Note-5: Inspect & maintain specified torque.

Note-6: Inspect the bearings free play, replace if necessary.

Note-7: Replace once in a every two years or **30000** km, whichever is earlier.

Note-8: Inspect for any play in the mounting bushes, replace if necessary.

Note-9: Check idle CO emission along with idle r/min/idle CO adjustment (if required).








Note-10: Inspect the hoses for deterioration, damage or loose connections and canister for cracks or other damages.












Note: Always wipe the water from the vehicle after washing. Use clean soft cloth or pressurized air for completely drying the water.

Dear Customer,

MAINTENANCE SCHEDULE

We would strongly recommend the following schedule, to keep your vehicle in perfect running condition and healthy environment. Vehicle subjected to severe use or ridden in dusty area will require more frequent servicing.

ITEMS	SERVICE	1 st	2 nd	3 rd	4 th	5 th	6 th	7 th	8 th	9 th	10 th	11 th
	DAYS	1st 60	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90
	Km Note-1	500-750	3000-3500	6000-6500	9000-9500	12000-12500	15000-15500	18000-18500	21000-21500	24000-24500	27000-27500	30000-30500
Fuel Line		I	I	I	I	I	I	I	I	I	I	I
 Throttle Operation		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A
 Carburetor/Engine Idle Speed		C, A	A	C, A	A	C, A	A	C, A	A	C, A	A	C, A
Air Cleaner Element	Note-2	C	C	C	C	R	C	C	C	R	C	C
Spark Plug		I, C, A	I, C, A	I, C, A	I, C, A	R	I, C, A	I, C, A	I, C, A	R	I, C, A	I, C, A
 Valve Clearance		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A
Engine Oil	Note-3	O	I, T	O	I, T	O	I, T	I, T	O	I, T	O	I, T
 Engine Oil Strainer Screen		C		C		C		C		C		C
 Engine Oil Centrifugal Filter		C		C		C		C		C		C
Electric Starter		I	I	I	I	I	I	I	I	I	I	I
 Electric Starter Chain		L		L		L		L		L		L
Oil Circulation		I	I	I	I	I	I	I	I	I	I	I
 Drive Chain	Note-4	I, C, L, A at every 2000 km					I, C, L, A at every 2000 km					
Drive Chain Slider			I	I	I	I	I	I	I	I	I	I
Battery Voltage		I	I	I	I	I	I	I	I	I	I	I
Brake Shoe		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A

ITEMS		SERVICE	1 st	2 nd	3 rd	4 th	5 th	6 th	7 th	8 th	9 th	10 th	11 th	
		DAYS	1st 60	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90	Next 90
		Km Note-1	500-750	3000-3500	6000-6500	9000-9500	12000-12500	15000-15500	18000-18500	21000-21500	24000-24500	27000-27500	30000-30500	
	Brake System (Cam & Brake Pedal)			C, L		C, L		C, L		C, L		C, L		
	Stop Lamp Switch		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	
	Headlamp Focus		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	
	Clutch Lever Free Play		I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	I, A	
	Side Stand/Main Stand		L	L	L	L	L	L	L	L	L	L	L	
	Side Stand Switch		I, C	I, C	I, C	I, C	I, C	I, C	I, C	I, C	I, C	I, C	I, C	
	i3s System		I	I	I	I	I	I	I	I	I	I	I	
	Nut, Bolts & Fasteners	Note-5	I	I	I	I	I	I	I	I	I	I	I	
	Wheels Bearings	Note-6	I	I	I	I	I	I	I	I	I	I	I	
	Wheels/Tyres		I	I	I	I	I	I	I	I	I	I	I	
	Steering Head Bearing		I	I, A	I	I, A	I, L, A	I	I	I, A	I, L, A	I	I, A	
	Front Suspension/Oil Leakage	Note-7	I	I	I	I	I	I	I	I	I	I	I	
	Rear Suspension	Note-8	I	I	I	I	I	I	I	I	I	I	I	
	Secondary Air Injection				I		I		I		I		I	
	Muffler (Catalytic Converter)	Note-9			I, E		I, E		I, E		I, E		I, E	
	Evaporative Emission Control System	Note-10	I	I	I	I	I	I	I	I	I	I	I	